

Ballistic XFrame™, Brokos Belt & Tactical Base Belt Assembly



FIGURE A



FIGURE B



FIGURE C



FIGURE D



FIGURE E



FIGURE F



FIGURE G



FIGURE H



FIGURE I

Insert the XFrame™ Stays into Stay Channel which is located in the lower back of your TYR Tactical™ Carrier (**Figure A**). The top of the Stays should clear Channels by 2" (**Figure B**). Attach webbing to give min./max. range for XFrame™ Stays (**Figure C & D**). Adjust the XFrame™ Stays to 1 of 4 angle attachment points (**Figure E**) provided on XFrame™ Brokos Belt to meet the end user's body type and comfort. Secure the stays (**Figure F & G**).

Secure the back closure of the XFrame™ Brokos Belt via tri-glide in-conjunction with hook and loop (**Figure H & I**). To obtain the proper fit, bend slightly forward and set the Belt in the desired location then tighten. After the XFrame™ Brokos Belt is set, adjust and tighten Base Belt to desired fit, comfort and load.