


TYR TACTICAL® BELT SIZING




XFRAME® & LOAD CARRIAGE GUNFIGHTER® BELT SIZING



Measure over your clothing from inside one hip bone to inside the other (FIGURE A). The ends of the belt should leave a **6" GAP** in the front of your waistline (FIGURE B). Once you have that total length, compare it to the chart below for belt sizing. If you desire a closer fit then simply measure leaving only a **3" GAP** to account for the Cobra® Buckle.

TOTAL LENGTHS OF THE BELTS BELOW REFLECT MEASUREMENTS FROM END-TO-END, NOT PANT SIZES.



APPLICABLE BELT SIZES:
TYR-GF-MAB/S-001

SMALL 26" - 30"	MEDIUM 29" - 33"	LARGE 32" - 36"	XLARGE 36" - 40"	2XLARGE 39" - 43"
--------------------	---------------------	--------------------	---------------------	----------------------

APPLICABLE BELT SIZES:
TYR-XF-BKBLB & TYR-BKBLB

SMALL 26"	MEDIUM 30"	LARGE 34"	XLARGE 38"	2XLARGE 42"
--------------	---------------	--------------	---------------	----------------

XFRAME® STAY SIZING

MEASURE FROM THE CENTER OF THE SCAPULA TO THE TOP/CENTER OF GLUTE.

XFrame® Stay Sizes:
14", 15", 16", 17",
18", 19", 20", 22"

